SANTA MONICA PROPER

AIR CONDITIONING INSTRUCTIONS

Confirm Fan Setting

- Ensure the AC unit is set to “ON” and not “AUTO.”
- The “ON” setting will create continuous cold or hot air flow.
- In the “AUTO” setting, the fan runs continuously, even when the AC is not actively cooling or heating.

If the unit is set to AUTO, guide the guest to switch it to ON.

If the unit is set to OFFLINE, tap with three fingers and press the BACK button to return to your last setting. To confirm it is running, press ON.

Changing the Temperature

- Press the up arrow to increase the temperature (warmer).
- Press the down arrow to decrease the temperature (cooler).

Heating: (above 71 degrees)
May take approximately 30–40 minutes to reach the desired temperature, depending on the room’s starting temperature.

Cooling: (below 69 degrees)
May take up to one hour or longer, depending on guestroom location and sun exposure.